

请自行修改对应产品图以及对应型号
说明书尺寸请根据产品自身说明书尺寸进行调节

Here We Show Only Cover Page/first Page. inside Must Be Show/print The Active Instructions. after U Add The Active Instructions. please Send Us By Return Email For Final Confirmation

此设计是封面/第一页，内页必须要有详细的使用说明，有商标的地方必须换成我公司的商标
请把改好的完整的说明书，发电子邮件给我公司以供最后的确认

Cover page

First page

USER MANUAL

GEEPAS[®]
2.0 COMPUTER SPEAKER



Please read the manual fully before using the product. Please keep the manual safe for future reference.

MODEL NO.: GMS11124UK
www.geepas.co.uk

For you. For life.

Dear Customer,

You are now a proud owner of a Geepas product. Let's welcome you to the Geepas customer family. We hope you will be happy using it as millions of our satisfied customers already are. Our products continue to be the favorites on account of their superior quality, reliability and performance.

In order to provide you the ultimate satisfaction, the minutest part of each product is thoroughly tested and examined under stringent conditions. The objective of Geepas is to bring cutting edge technology to your everyday life.

In the unlikely event that the product needs warranty service, please refer the enclosed warranty card.

Although it is highly improbable, yet in case you have any issues with the product kindly contact your nearest Geepas dealer or get in touch with us directly. We assure you that an appropriate action would be taken as per our customer service policy.

Before you start enjoying the product we strongly urge you to spare a few minutes to go through this manual so that you may derive the maximum benefits out of the product.

1

General Safety Guidelines

Read the user manual before operating any appliance or equipment.

1. Do not operate any equipment with a damaged power cord.
2. Check the voltage available at your home and ensure that it matches with the voltage mentioned on your appliance before switching it on.
3. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are under supervision or have been given correct and necessary instructions.
4. Always keep the unit on a dry and flat surface.
5. Never touch any appliance or equipment with wet or damp hands.
6. While plugging or unplugging a power cord, hold it by the plug, never pull the cord.
7. Do not use any attachments other than the ones supplied by or specified by the manufacturer.
8. Never leave the unit unattended while in operation especially, when children are around.
9. The equipment are for household use only. Do not use it for commercial purposes.
10. All appliances and equipment are designed for indoor use. Do not use them outdoors unless specifically mentioned in the instruction manual.
11. Do not connect the equipment to an extension cord or a multiple socket adaptor. Always connect the unit to the main socket; this is to prevent short circuits and sparks, which can shorten the life of the unit and prove risky for your life.
12. Do not let the power cord to hang over the edge of the table or work surface since a sharp edge can damage the cable over a period of time. Do not let it get tangled or come into contact with a hot surface.
13. Do not attempt to repair the unit in case of any malfunction. Always take it to an authorized service center.
14. Always unplug the unit from the power source during lightning and thunderstorms, or when the unit is not going to be used for a long period of time.
15. To avoid risk of electric shocks, do not immerse the equipment in water or use it in damp conditions.
16. The unit should be cleaned with a damp cloth and immediately wiped dry. Do not use detergents or chemical cleaning agents to clean the unit.
17. Always clean cooking appliances soon after use. This will prevent food from sticking to the unit and the possible bacterial growth.
18. If the power cord is damaged, please get it replaced at the service center or by a person who is designated by the manufacturer or a qualified person, in order to avoid electric shock.

إرشادات السلامة العامة

اقرأ دليل المستخدم قبل تشغيل أي جهاز

١. لا تقم بتشغيل أية أجهزة بسلك طاقة تالف.
٢. تحقق من الفولتية المتوفرة في منزلك وتأكد من مطابقتها للجهد المذكور على الجهاز قبل تشغيله.
٣. لا يجوز استخدام الجهاز من قبل الأشخاص (بالإضافة للأطفال) بقدرات مادية أو حسية أو عقلية منخفضة، أو عدم وجود خبرة ومعرفة، إلا إذا كانوا موجودين تحت إشراف أو تم إعطاء التعليمات الصحيحة والضرورية.
٤. احتفظ بالوحدة دائماً على سطح جاف ومسطح.
٥. لا تلمس أبداً أي جهاز بأيدي مبللة أو رطبة.
٦. أثناء توصيل سلك الطاقة أو فصله، احتفظ به بواسطة القابس، ولا تسحب سلك الكبل.
٧. لا تستخدم أي مرفقات بخلاف المرفقات المقدمة من قبل الشركة المصنعة أو المحددة منها.
٨. لا تترك الوحدة دون مراقبة أثناء تشغيلها خصوصاً عندما يكون الأطفال حولها.
٩. المعدات للاستخدام المنزلي فقط. لا تستخدمها لأغراض تجارية.
١٠. جميع الأجهزة والمعدات مصممة للاستخدام في الأماكن المغلقة. لا تستخدمها في الهواء الطلق ما لم يذكر على وجه التحديد في دليل التعليمات.
١١. لا تقم بتوصيل الجهاز بسلك توصيل أو بمحول مقبس متعدد. قم دائماً بتوصيل الوحدة بالمقبس الرئيسي؛ هذا هو لمنع الدوائر القصيرة والشرر، والتي يمكن أن تقصر عمر الوحدة وتثبت خطراً على حياتك.
١٢. لا تدع سلك الكهرباء معلقاً على حافة الطاولة أو سطح العمل نظراً لأن الحافة الحادة قد تؤدي إلى تلف الكابل على مدى فترة زمنية. لا تدعها تتشابك أو تتلامس مع سطح ساخن.
١٣. لا تحاول إصلاح الوحدة في حالة حدوث أي عطل. خذها دائماً إلى مركز خدمة معتمد.
١٤. قم دائماً بفصل الوحدة عن مصدر الطاقة أثناء الصواعق والعواصف الرعدية، أو عند عدم استخدام الوحدة لفترة طويلة من الزمن.
١٥. لتجنب خطر التعرض للصدمات الكهربائية، لا تغمس المعدات في الماء أو لا تستخدمها في ظروف رطبة.
١٦. يجب تنظيف الوحدة بقطعة قماش رطبة ومحوها على الفور. لا تستخدم المنظفات أو مواد التنظيف الكيميائية لتنظيف الوحدة.
١٧. قم دائماً بتنظيف أجهزة الطهي بعد الاستخدام. هذا سيمنع الطعام من الالتصاق بالوحدة والنمو البكتيري المحتمل.
١٨. في حالة تلف سلك الطاقة، يرجى استبداله في مركز الخدمة أو عن طريق شخص معين من قبل الشركة المصنعة أو شخص مؤهل، لتجنب الصدمات الكهربائية.

Manual GMS11124UK

Thank you for purchasing these 2.0-channel computer speakers. They can be connected to your computer or any other multimedia device via a USB port for power and a stereo jack for sound. For volume, you can use the integrated volume button.


Features:

1. Drivers: 2.5" 3ohm (2pcs)
2. Cable: 1.3m, Black
3. Satellite: 90x115x160 (WxDxH), black
4. Frequency Response: 90Hz~20Khz
5. SN≥70dB
6. Plug: USB, 3.5mm stereo jack
7. Power Input: DC 5V/USB power

Installation and Utilization:

Plug and play: No program installation is needed to use this set of speakers as it works through a USB connection, the program of which is common to Windows OS. Simply plug the speakers into the USB port of your desktop computer or your notebook, and the jack plug to Line In of your sound card to start using them.

Place the speakers on a plane surface. The position and the distance of the speakers can be set as per your wish. Adjust the volume as desired and keep it at a reasonable level.



Note:

- Do not disassemble or modify this product.
- Do not use the product with wet hands.
- Keep the product away from dust and hot places.
- Keep the product away from water.

FAQs and Troubleshooting:

If you cannot hear any sound:

Check if you have plugged the speakers correctly. Check if the speakers and the sound card are working. Also, check the volume level on the speaker and that of the OS. If these peripherals are fine, then check if the USB port is defective. Insert another USB-ready appliance, such as a USB mouse or keyboard to test the USB port's functioning.

GMS11124UK دليل المستخدم

شكرًا لك على شراء مكبرات الصوت هذه التي تتضمن قناة 2.0. يمكن توصيلها بجهاز الكمبيوتر الخاص بك أو أي جهاز وسائط متعددة آخر عبر منفذ USB لتوفير الطاقة ومقيس استريو للصوت. بالنسبة إلى مستوى الصوت ، يمكنك استخدام زر الصوت المدمج.


المواصفات :

1. دريفرس: 2.5" 3PCS)2 ohm
2. كابل: 1.3 م ، أسود
3. سائتلة : (WxDxH) 90 x115x160 ، أسود
4. استجابة التردد: 90 Hz ~ 20Khz
5. SN ≥ 70dB
6. قابس USB :، جاك ستيريو 3.5 ملم
7. مدخلات الطاقة : DC 5V / USB

التهيئة والاستخدام

التوصيل والتشغيل: لا يلزم تثبيت البرنامج لاستخدام هذه المجموعة من السماعات أثناء عملها عبر اتصال USB ، وهو برنامج شائع لنظام التشغيل windows OS ما عليك سوى توصيل السماعات بمنفذ USB الخاص بجهاز كمبيوتر سطح المكتب أو الكمبيوتر الدفتري الخاص بك ، ومقيس التوصيل إلى الخط في بطاقة الصوت لبدء استخدامها.

ضع السماعات على سطح مستو. يمكن تحديد موضع ومسافة مكبرات الصوت حسب رغبتك. اضبط مستوى الصوت على النحو المطلوب واحتفظ به عند مستوى معقول



الملاحظة :

- لا تقم بفك أو تعديل هذا المنتج.
- لا تستخدم المنتج بأيدي مبللة.
- ابق المنتج بعيدًا عن الأتربة والأماكن الساخنة.
- احتفظ بالمنتج بعيدًا عن الماء.
- الأسئلة الشائعة واستكشاف الأخطاء وإصلاحها: إذا لم تستطع سماع أي صوت:

تحقق مما إذا كنت قد قمت بتوصيل مكبرات الصوت بشكل صحيح. تحقق من عمل مكبرات الصوت وبطاقة الصوت. أيضا ، تحقق من مستوى الصوت على مكبر الصوت وأن من نظام التشغيل. إذا كانت هذه الأجهزة الطرفية جيدة ، فتأكد من خلل منفذ USB. أدخل جهازًا آخر يعمل بنظام USB ، مثل ماوس USB أو لوحة مفاتيح لاختبار أداء منفذ USB.

Contact details

Western International Group (UK) Ltd
Unit 27, Kelvin Way Trading Estate,
West Bromwich, Birmingham, B70 7TP,
United Kingdom

Customer Service / Technical Support

Telephone: 01217286969
Email: support@geepas.co.uk
Web: www.geepas.co.uk
*Register online for warranty.

Disposal of the appliance

	<p>Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in the European Union and other European countries with separate collection systems)</p> <p>This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.</p> <p>Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business user should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.</p>
---	--



RoHS
Compliant

