

请自行修改对应产品图以及对应型号
说明书尺寸请根据产品自身说明书尺寸进行调节



Here We Show Only Cover Page/first Page. inside Must Be Show/print The Active Instructions. after U Add The Active Instructions. please Send Us By Return Email For Final Confirmation

此设计是封面/第一页，内页必须要有详细的使用说明，有商标的地方必须换成我公司的商标

请把改好的完整的说明书，发电子邮件给我公司以供最后的确认

Cover page

First page



General Safety Guidelines

Read the user manual before operating any appliance or equipment.


1. Do not operate any equipment with a damaged power cord.
2. Check the voltage available at your home and ensure that it matches with the voltage mentioned on your appliance before switching it on.
3. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are under supervision or have been given correct and necessary instructions.
4. Always keep the unit on a dry and flat surface.
5. Never touch any appliance or equipment with wet or damp hands.
6. While plugging or unplugging a power cord, hold it by the plug, never pull the cord.
7. Do not use any attachments other than the ones supplied by or specified by the manufacturer.
8. Never leave the unit unattended while in operation especially, when children are around.
9. The equipment are for household use only. Do not use it for commercial purposes.
10. All appliances and equipment are designed for indoor use. Do not use them outdoors unless specifically mentioned in the instruction manual.
11. Do not connect the equipment to an extension cord or a multiple socket adaptor. Always connect the unit to the main socket; this is to prevent short circuits and sparks, which can shorten the life of the unit and prove risky for your life.
12. Do not let the power cord to hang over the edge of the table or work surface since a sharp edge can damage the cable over a period of time. Do not let it get tangled or come into contact with a hot surface.
13. Do not attempt to repair the unit in case of any malfunction. Always take it to an authorized service center.
14. Always unplug the unit from the power source during lightning and thunderstorms, or when the unit is not going to be used for a long period of time.
15. To avoid risk of electric shocks, do not immerse the equipment in water or use it in damp conditions.
16. The unit should be cleaned with a damp cloth and immediately wiped dry. Do not use detergents or chemical cleaning agents to clean the unit.
17. Always clean cooking appliances soon after use. This will prevent food from sticking to the unit and the possible bacterial growth.
18. If the power cord is damaged, please get it replaced at the service center or by a person who is designated by the manufacturer or a qualified person, in order to avoid electric shock.

إرشادات السلامة العامة

اقرأ دليل المستخدم قبل تشغيل أي جهاز


١. لا تقم بتشغيل أية أجهزة بسلك طاقة تالف.
٢. تحقق من الفولتية المتوفرة في منزلك وتأكد من مطابقتها للجهد المذكور على الجهاز قبل تشغيله.
٣. لا يجوز استخدام الجهاز من قبل الأشخاص (بالإضافة للأطفال) بقدرات مادية أو حسية أو عقلية منخفضة ، أو عدم وجود خبرة ومعرفة ، إلا إذا كانوا موجودين تحت إشراف أو تم إعطاء التعليمات الصحيحة والضرورية.
٤. احتفظ بالوحدة دائماً على سطح جاف ومسطح.
٥. لا تلمس أبداً أي جهاز بأيدي مبللة أو رطبة.
٦. أثناء توصيل سلك الطاقة أو فصله ، احتفظ به بواسطة القابس ، ولا تسحب سلك الكيل.
٧. لا تستخدم أي مرفقات بخلاف المرفقات المقدمة من قبل الشركة المصنعة أو المحددة منها.
٨. لا تترك الوحدة دون مراقبة أثناء تشغيلها خصوصاً عندما يكون الأطفال حولها.
٩. المعدات للاستخدام المنزلي فقط. لا تستخدمها لأغراض تجارية.
١٠. جميع الأجهزة والمعدات مصممة للاستخدام في الأماكن المغلقة. لا تستخدمها في الهواء الطلق ما لم يذكر على وجه التحديد في دليل التعليمات.
١١. لا تقم بتوصيل الجهاز بسلك توصيل أو بمحول مقبس متعدد. قم دائماً بتوصيل الوحدة بالمقبس الرئيسي ؛ هذا هو لمنع الدوائر القصيرة والشرر ، والتي يمكن أن تقصير عمر الوحدة وتثبت خطراً على حياتك.
١٢. لا تدع سلك الكهرباء معلقاً على حافة الطاولة أو سطح العمل نظراً لأن الحافة الحادة قد تؤدي إلى تلف الكابل على مدى فترة زمنية. لا تدعها تتشابك أو تتلامس مع سطح ساخن.
١٣. لا تحاول إصلاح الوحدة في حالة حدوث أي عطل. خذها دائماً إلى مركز خدمة معتمد.
١٤. قم دائماً بفصل الوحدة عن مصدر الطاقة أثناء الصواعق والعواصف الرعدية ، أو عند عدم استخدام الوحدة لفترة طويلة من الزمن.
١٥. لتجنب خطر التعرض للصددمات الكهربائية ، لا تغمس المعدات في الماء أو لا تستخدمها في ظروف رطبة.
١٦. يجب تنظيف الوحدة بقطعة قماش رطبة ومحوها على الفور. لا تستخدم المنظفات أو مواد التنظيف الكيميائية لتنظيف الوحدة.
١٧. قم دائماً بتنظيف أجهزة الطهي بعد الاستخدام. هذا سيمنع الطعام من الالتصاق بالوحدة والنمو البكتيري المحتمل.
١٨. في حالة تلف سلك الطاقة ، يرجى استبداله في مركز الخدمة أو عن طريق شخص معين من قبل الشركة المصنعة أو شخص مؤهل ، لتجنب الصدمات الكهربائية.

Configuration



User instructions

1. Please check the voltage match with this machine.
2. Set the switch to "OFF".
3. Take the cup, and fill in the machine with 1 cup of corn and ONLY 1 cup corn time.
4. Fit the cup and the upper cover into the machine.
5. Set the switch to "ON".
6. After powered 3 minutes, the hot popcorn comes out from the outlets.
7. Push the switch to "OFF", when the popcorn finished.
8. For the continuous working, at 15 minutes gap between the second time.



Add salt/oil/cream to the box

Safety Alerts

1. DO NOT add any salt/oils/cream, to the machine.
2. DO NOT touch the upper cover, nor the inner parts when machine running or hot.
3. DO NOT leave it to children or disabled;
4. For the continuous working, AT LEAST 15 MINUTES gaps is required.
5. DO NOT detach it by yourself when the machine is out of order.
6. When the power cord/wire line is broken, DO not use it or repair it by yourself.

7. Keep the machine dry, and indoor use only.
8. DO not clean it when the machine is hot.
9. Keep off from hot, wet or explosive environment.
10. DO NOT block the wind-in-let when the machine running.

GUARANTEE

This product is guaranteed for a period of a year from the date of purchase.

This service is free only at the following conditions.

This guarantee covers all substitutions of repairs due to material or manufacturing defects, and has no validity in the following cases:

- 1) Transport damage of falling.
- 2) Infringement or modify.
- 3) Accidents due to an incorrect or improper installation.
- 4) Wrong connecting to the higher voltage.
- 5) Repair carried out by unauthorized technical servicing centers.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.



ارشادات الاستعمال

1. يرجى فحص الفلطوبة مناسبة لهذا الجهاز
2. ضبط المفتاح الى جهة " اغلاق "
3. يملأ المحرك بكوب من ذرة ، كوب واحد فقط في مرة
4. تثبيت كوب المحركة والجفن الاعلى الى المحركة
5. ضبط المفتاح الى جهة " فتح "
6. وبعد تشغيل ثلاثة دقائق تخرج ذرة ممحصاة حارة من المنافذ
7. يغلق الجهاز بتحريك المفتاح الى جهة " اغلاق " بعد تمام الفشار
8. يرجى فرجة ١٥ دقيقة بين مرة اخرى لتشغيل مستمر



إضافة الملح / النفط / كريم إلى المربع

انذار الامن

1. لا يضاف ملح / زيت / كريم الى المحركة
2. ولا يلمس الجفن والاجزاء الداخلي عند تشغيل المحركة او تكون حارة
3. ولا تترك المحركة عند الاطفال والمعوقين
4. يلزم فرجة ١٥ دقيقة على الاقل لتشغيل مستمر
5. ولا تفك المحركة بنفسك عند ما تكون المحركة خارج الخدمة
6. يرجى عدم الاصلاح بنفسك عند وجود ضرر في سلك كهربائي او عند انقطاع السلك
7. تحفظ المحركة جافة وتستعمل في الداخل فقط
8. يرجى عدم تنظيف المحركة عند ما تكون حارة
9. تحفظ المحركة عن بيئة حارة او رطب او من مادة متفجرة

الضمان

يتوفر هذا الجهاز ضمان سنة واحدة من تاريخ الشراء ، وهذه الخدمة متوفرة مجاناً حسب الشروط الاتية:
وهذا الضمان يشمل كل الاستبدال والاصلاح لضرر صناعية او مادية ، ولايشتمل الضمان الاحوال التالية:

1. ضرر عند النقل بسقوط
2. الاخلال والتغيير
3. الخطر بسبب تركيب خطأ او غير مناسب
4. وصلة خطأ الى فلطوبة عالية
5. الاصلاح من مراكز تقنية غير مخولة

ولا يصلح استعمال هذا الجهاز للاشخاص (بالاضافة الاطفال) المعوقين الذهنية والحسية والعقلية او بدون خبرة وتجربة ومعرفة عنه ان لم يسمح بمراقبة او ارشاد على استعمال الجهاز من قبل شخص مسؤول على الامن والسلامة ، يلزم المراقبة على عدم لعب الاطفال بالجهاز

Contact details

Western International Group (UK) Ltd
Unit 27, Kelvin Way Trading Estate,
West Bromwich, Birmingham, B70 7TP,
United Kingdom

Customer Service / Technical Support

Telephone: 01217286969

Email: support@geepas.co.uk

Web: www.geepas.co.uk

*Register online for warranty.

Disposal of the appliance



Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)
This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business user should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

