


请自行修改对应产品图以及对应型号  
说明书尺寸请根据产品自身说明书尺寸进行调节

Here We Show Only Cover Page/first Page, inside Must Be Show/print The Active Instructions. after U Add The Active Instructions, please Send Us By Return Email For Final Confirmation  
此设计是封面/第一页，内页必须要有详细的使用说明，有商标的地方必须换成我公司的商标  
请把改好的完整的说明书，发电子邮件给我公司以供最后的确认

Cover page



First page



# USER MANUAL

## General Safety Guidelines

- Read the user manual before operating any appliance or equipment.
- Check the voltage available at your home and ensure that it matches with the voltage mentioned on your appliance, before switching it on.
  - The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are under supervision or have been given correct and necessary instructions.
  - If the power cord is damaged, please get it replaced at a service center or by a person who is designated by the manufacturer or a qualified person, in order to avoid electric shock.
  - Always keep the unit on a dry and flat surface.
  - Never touch any appliance or equipment with wet or damp hands.
  - While plugging or unplugging a power cord, hold it by the plug; never pull the cord.
  - Do not connect the equipment to an extension cord or a multiple socket adaptor. Always connect the unit to the main socket; this is to prevent short circuits and sparks, which can shorten the life of the unit and prove risky for your life.
  - Do not let the power cord hang over the edge of the table or a work surface as a sharp edge can damage the cable over a period of time.
  - Do not let it get tangled or come into contact with a hot surface.
  - Do not attempt to repair the unit in case of any malfunction, always take it to an authorized service center.
  - Do not use any attachments other than the ones supplied by or specified by the manufacturer.
  - Never leave the unit unattended while in operation especially, when children are around.
  - Children should be supervised to ensure that they do not play with the appliance.
  - The equipment is for household use only, do not use it for commercial purposes.
  - All appliances and equipment are designed for indoor use. Do not use them outdoors unless specifically mentioned in the instruction manual.
  - Always unplug the unit from the power source during lightning and thunderstorms, or when the unit is not going to be used for a long period of time.
  - To avoid risk of electric shocks, do not immerse the equipment in water or use it in damp conditions.
  - The unit should be cleaned with a damp cloth and immediately wiped dry. Do not use detergents or chemical cleaning agents to clean the unit.
  - WARNING:** If the surface is cracked, switch off the appliance to avoid electric shock.



Children younger than 3 must not use the appliance due to their inability to react to operate the appliance.

For you. For life.

## نقطة ملامة عامة

- غير انتقال المستمر قبل تشغيل أي جهاز
- تحفظ من التوصيات المتوفرة في متجرك، وذلك من مطابقتها للمهد المذكور على الجهاز ، قبل تشغيله.
  - لا يجوز استخدام الجهاز من قبل الأطفال (الإمساك بالأنفاس) بغيرات مائية أو حسية أو عملية منخفضة ، أو عدم وجود خبرة وخبرة ، ولا كلها تحت إشراف أو تم اعطاء التعليمات الصحيحة والضرورية.
  - لا تقم بالتحقق أنه الجهاز لها سلك مثقال الماء.
  - في حالة تلف سلك الطاقة ، يرجى استبداله من مركز خدمة أو بواسطة شخص معين من قبل الشركة المصنعة أو شخص موثوق ، لتجنب الصدمات الكهربائية.
  - احفظ بالوحدة دائمًا على سطح جاف ومستوى.
  - لا تنسى أبداً أن جهاز يأخذ مياه أو رطوبة.
  - الناء بوصول سلك الطاقة أو غسله ، احتفظ به بواسطة القابس ، أبداً لا تنسى ذلك.
  - لا تقم بوصول الجهاز سلك بوصول م Abbas مصدر ، فر داداً بوصول الوحدة بال بنفس الرئيس ، هذا هو لمنع الدوار التصوّر والتزوير ، والتي يمكن ان تضر بغير الوحدة والتلف خطير على جهازك.
  - لا تدع سلك الطاقة يمتد على سطح الطاولة أو على سطح العمل لأن العادة العادلة قد تؤدي إلى تلف الكابل على مدى فترة زمنية ، لا تدعها تتلامس أو تتلاصق مع سطوح ساخنة.
  - لا تحرر أقسام الوحدة في حالة وجود أي سلك ، فلذلك دائمًا في مركز خدمة معتبر.
  - لا تستعمل أي مرفقات غير المرفقات المقدمة من قبل الشركة المصنعة أو المحدثة منها.
  - ترك الوحدة دون مرافق أثناء التخلصها مسؤوليتها معاً يكون الأطفال مولها.
  - يجب الارتكاب على الأطفال لتنكر لهم لا يأخذون مع الجهاز.
  - الوحدات مخصصة لاستخدام العائلة فقط ، لا يستخدمها لأغراض تجارية.
  - ضع الأجهزة والمعدات مصممة لاستخدامها في الأماكن المغلقة ، لا يستخدمها في الهواء الطلق ما لم يذكر على وجه التحديد في تلك التعليمات.
  - فر داداً بوصول الوحدة عن مصدر الطاقة أثناء السفر والمواصلات الرئوية ، أو عند عدم استخدام الوحدة فترة طويلة من الزمن.
  - تجنب نظر العيون للجهاز الكهربائية ، لا تمس العيون في حالة أو استخدامها في قبوق وربط.
  - يجب تنظيف الوحدة بقطعة قماش رطبة ومجففة على الفور. لا تستخدم المطهرات أو مواد التنظيف الكيميائية لتنظيف الوحدة.
  - تحذير: إذا كان السطح مكتبراً ، فلم يليق تشغيل الجهاز لتجنب الصدمات الكهربائية.



سوانس عدم استخدام الجهاز بسبب عدم قدرتهم على تشغيل الجها

# USER MANUAL

## INTRODUCTION

- Thank you for purchasing our air cooler.
- Each unit has been manufactured to ensure safety and reliability.
- Before first use, read the instructions carefully and keep it for further reference.

## PERFORMANCE PARAMETERS

Model	Rating Power	Power	Max Water Injection Rate
GAC957BN	220-240V~ 50/60Hz	80W	20L

## KNOW YOUR AIR COOLER



1. Place your air cooler at least 10cm away from wall or any other obstruction. The cooler should be placed near a window/door to allow in fresh air.
2. Always ensure that there is another open window/door through which warm air can exhaust from the room. Constant air change is very essential for fresh air cooling by your air cooler!
3. Plug in the mains cord of your air cooler to a wall socket. Ensure the plug is properly earthed and is in off position while plugging

## FUNCTIONS

- Principle of Cooling: Water is taken from the water tank by pump to the top, then the water drops into paper evaporator. When the water in paper evaporator evaporates to water vapor, the air is cooled. People will feel cool wind when the cool air is delivered by fan.
- Electronics control: safe and durable, attractive appearance.
- Adjustable speed and fan type: have three speeds and fan types, blow at a wide angle.
- Cooling: Through air evaporating, cut down the air temperature and raise relative humidity.
- Deliver wind at a wide angle: swing the blades automatically, deliver wind at horizontal wide angle. Swing the blades transversely manually, select the direction discretionary.

## ASSEMBLING AND WATERING

1. Assembling castors: put the appliance on a flat surface, take out the wrench from foam box, then assemble the castors.

For you. For life.

2. Watering: pull 1/3 water tank, then add clean water.

### Attention:

- a. Pay attention to the level of water tank when add water.
- b. The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.
- c. Put ice or frozen ice box to the water tank if you want to strengthen the efficiency of cooling. But the total level of water tank should not over "MAX" scale.

## OPERATION

- ON/OFF key: after it is connected to the power supply, the cooling fan will enter standby state , knob "1,2,3" the machine will start to work; knob "0" to turn off the fan.
- Wind speed key: Low speed(1)-Moderate speed(2)-High speed(3)
- Vane swinging key: press swing key, the wind can automatically swing left and right.
- Cold air key: turn on this switch to start cold air function.  
**IMPORTANT:** Please be sure there is enough water in the water tank before press this key.

## THE USE OF ICE BOX

The ice box has a particular feature of keeping cool. It can absorb heat and let the water temperature below the environmental temperature.

### Using methods:

- a. add water to the ice box (not over max level) and put it into the refrigerator to make sure that it iced absolutely.
- b. Open the door, put the frozen ice box into the water tank.
- c. There have two ice boxes , can be used circularly.

## CAUTION

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, it should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. When the appliance is not in use, switch off and unplug it.
6. Do not insert foreign things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas. Avoid long-term direct solar radiation.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.

# USER MANUAL

11. After adding water to the water tank, do not tilt or knock over it when you put or move. If you want to move, please push slowly from the side, in order to avoid spilling.
12. Do not turn over the appliance. If it is tipped over and there are some water in the body, should unplug the power supply first. Then send it to the repair department or after-sales service and overhaul the appliance.
13. Do not cover the air vent.
14. Clean the appearance with a lightly damp cloth. Do not use any type of detergents or solutions. Do not rinse the appliance.
15. Do not make air outlets and inlets near the wall or curtain.
16. Do not knock or shake the body when using, otherwise it may cause stop automatically.
17. The water in tank will easily metamorphose and has odor in summer, please renew the water frequently.
18. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
19. Children should be supervised to ensure that they do not play with the appliance.
20. To avoid the risk caused by instability of unit, you must fix the unit firmly according to manual book.
21. Fan for temperate climates only.
22. Should it be necessary to move the unit after the water has been added, roll gently to the required position and activate the bracket the castors.
23. The power cord is with "Y" type connection and it must be changed by professional technicians if necessary.

## CLEANING AND MAINTENANCE

**WARNING:** Ensure that the fan is switched-off from the supply mains before removing the air filter screen.

1. Clean the air filter screen  
Cut off the power supply, pull the handle of air filter screen, remove it from appliance. Clean the air filter screen with neutral detergent and baristor brush, then clean it with clear water. Finally, re-install to the appliance.
2. Clean the wet pad  
Cut off the power supply, take down the air filter screen, then draw the wet pad from support. Clean the wet pad with neutral detergent and baristor brush, then clean it with clear water. Finally, re-install to the appliance.  
**Attention:** the wet pad must be installed horizontally, in order to avoid leaking.
3. Clean the water tank  
Cut off the power supply, open the door, take out the water tank, clean it with neutral detergent, and wash it with clear water, then re-install to the appliance.
4. Clean the shell  
Clean with neutral detergent and soft cloth.  
**Attention:** cut off the power supply when clean the appliance as there have a high

For you. For life.

pressure in the body. Do not leave any water on the surface of control panel.


## MALFUNCTION AND MAINTENANCE

Malfunction	Causes	Solution
No action	1. Power off or poor connection. 2. Not press the "ON" key on the control panel.	1. Plug the power cord and make sure it connects well. 2. Press the "ON" key on the control panel.
Poor effect of dehumidifying	1. Block the air filter screen with dust. 2. Block the air inlet with foreign things..	1. Purify the air filter screen. 2. Remove foreign things from the air inlet.

Repair the appliance under the situation as follows:

1. Abnormal action or no action, it is invalid by the above approach.
2. Abnormal action caused by ingress of water or foreign things.

## Wiring Diagram of Air Cooler



Unplug the appliance during filling and cleaning.

# USER MANUAL

المقدمة																	
تم تصميم كل واحدة من ملصق السلامة والموتوغيرا																	
قبل الاستخدام لأول مرة ، قرأ التعليمات بدقة واحتفظ بها لأخدك من الرجوع إليها.																	
<b>معلومات الاتصال</b>																	
<table border="1"> <thead> <tr> <th>العنوان</th> <th>العنوان</th> <th>العنوان</th> <th>العنوان</th> <th>العنوان</th> <th>العنوان</th> </tr> </thead> <tbody> <tr> <td> DAC9576N</td> <td>220-240 فولت - 50/60 هرتز</td> <td>80 أمبير</td> <td>تر</td> <td>20</td> <td>جدة مطرية</td> </tr> </tbody> </table>						العنوان	العنوان	العنوان	العنوان	العنوان	العنوان	DAC9576N	220-240 فولت - 50/60 هرتز	80 أمبير	تر	20	جدة مطرية
العنوان	العنوان	العنوان	العنوان	العنوان	العنوان												
DAC9576N	220-240 فولت - 50/60 هرتز	80 أمبير	تر	20	جدة مطرية												
<b>تعرف على جزء الهراء المذكور</b>																	
 <p>1. جزء الهراء على بعد 10 سم على الأقل من العاطل أو أي جزء آخر، يجب وضعه بعيداً وبكلور من الماء / يجب التباعد بعدوى الهراء كلثي. 2. ذلك ينبع من وجود KBD (أداة مفتوحة لفتح باب) في ملصق الهراء يمكن أن يفتح من خلال الهراء الذي من الممكن أن يفتح الهراء الذي يفتح من الهراء. 3. قد يتوصيل تلك التيار الكهربائي تدور الهراء وليس العاطل ذلك من أن نفس الهراء يمكن صياغة وفتحه مسبقاً وذلك في وضع يهدف لتنشئ التيار الكهربائي.</p>																	
<b>الوظائف</b>																	
<ul style="list-style-type: none"> <li>منذ التبريد ، يوصل الماء من ملصق الهراء بالملصقة إلى الأعلى ، ثم يصل إلى الماء في ملصق الهراء ، مما يتيح الماء الموجود في الماء الهراء إلى يدك الماء ، يتم تبريد الماء في ملصق الهراء.</li> <li>النافر ، في الماء الهراء ، يدخل الماء ، يتم تبريد الماء سريعاً ، ثم يخرج الهراء ، مما يتيح الهراء بوساطة الماء.</li> <li>النافر ، من خلال الهراء ، يدخل الماء ، مما ينبع منه ولوحة التحكم ، تفتح بزاوية واسعة.</li> <li>نافر الهراء يدخل الماء ، مما يفتح التيار الكهربائي ، وتوصيل الهراء إلى الماء ، مما يتيح الهراء بوساطة الماء.</li> <li>يشغل الهراء ، بعد الانتهاء التام.</li> </ul>																	
<b>التركيب وعمل الهراء</b>																	
<ol style="list-style-type: none"> <li>تركب الماء ، من الماء على سطح سير ، أخرج ملصق الهراء من ملصق الهراء ، ثم تم تركب الماء.</li> <li>ملصق الهراء ، من الماء ، ثم اضغط الماء على الماء.</li> <li>النافر ، من خلال الهراء ، مما يفتح التيار الكهربائي ، وتوصيل الهراء إلى الماء ، مما يتيح الهراء بوساطة الماء.</li> <li>يشغل الهراء ، بعد الانتهاء التام.</li> </ol>																	

# For you. For life.

- ملصق التشغيل (الملصق) بعد تركيبه يحيط بالماء ، ملصق جودة التبريد ، ولكن يجب الارتباط الماء
- الأهمي لجزء الهراء عن الملصق "الملصق"

- ملصق التشغيل (الملصق) بعد تركيبه يحيط بالماء ، ملصق جودة التبريد في حالة الاستخدام ، وملصق "3-2-1"
- الماء في العمل ، بعض "3" يلتف حول الماء
- ملصق جودة التبريد ، من "3" ملصق (1) ، من "3" ملصق (2) ، من "3" ملصق (3)
- ملصق جودة التبريد ، ملصق على ملصق التبريد ، يمكن تزيين آلة تردد الماء إلى السر ، ومن
- ملصق الهراء الماء ، تم تزيين آلة الماء ، مما يتيح الماء إلى جعل الهراء الماء ، مما يتيح الماء إلى هذا الماء

استخدام ملصق الهراء  
ملصق التشغيل ، من "3" ملصق على الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة

- طرق الاستخدام
  - آلة الماء إلى ملصق التشغيل (آلة الماء) ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة
  - آلة الماء ، ملصق التشغيل (آلة الماء) ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة
  - يوجه ملصق التشغيل ، يمكن استخدامها يمكن اختيار

- استخدام جيد التشغيل
  - لا يدخل الماء إلى الماء ، يحيط بالماء الماء ، وتركز تركيز الماء
  - لا يدخل الماء إلى الماء ، يحيط بالماء الماء ، وتركز تركيز الماء
  - في هذه ذات سلك الإتصال ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء التي يحيط بها الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء
  - يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء
  - يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء
  - يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء
  - يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء
  - يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- طرق التشغيل ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

- يحيط بالماء الماء ، يحيط بالماء الماء ، وتركز تركيز الماء إلى من درجة حرارة الماء

# USER MANUAL

10

18. إذا أجهز غير مختص لاستخدامه في تلك الأجهزة، فإن يكون من مسؤول الموزع الموزع الذي لا يملك الصلاحيات أو الخبرة أو المعرفة، بما ترمي به لهم الارتكاف أو الخطأ، المتعلقة باستخدام الجهاز من قبل الشخص المسؤول عن سلامته.
19. بعد إجراء الأفضلية التي لا يزيد عن يوم لا يتجاوز يومين.
20. يجب إدخال الموزع الذي لا يزيد عن يوم لا يتجاوز يومين، بحسب اتصاله بالموارد والمصالح.
21. جريدة الصحف المحلية.
22. إذا كان من المقرر في تحريك غير محدد بعد إصدارة المذكرة، فهو ينبع من إرادة الموزع والمصالح.
23. يمكن إمكان المطالبة برسوم من النوع "أ" بحسب المخواص المراسلة الذين ينبعون من إرادة الموزع.

## التنظيف والصيانة

- تحذر: لا ينبع من إلقاء التخلص المبرمج من مصدر التيار الكهربائي قبل إزالة الغطاء من مرجع الهواء.
1. ينبع من إلقاء التخلص المبرمج من مصدر التيار الكهربائي، وابتساب مجلس الشيوخ الكهربائي قبل إزالة الغطاء من مرجع مصدر وفرقة تراخيص، ثم إلقاء التخلص المبرمج، ويتم بذلك من العوائق، ينبع من إلقاء التخلص المبرمج.
  2. ينبع من إلقاء التخلص المبرمج من مصدر التيار الكهربائي، وفقاً لبيان مجلس الشيوخ الكهربائي، ثم إلقاء التخلص المبرمج، وذلك على العوائق، ينبع من إلقاء التخلص المبرمج.
  3. ينبع من إلقاء التخلص المبرمج، وفقاً لبيان مجلس الشيوخ الكهربائي، ثم إلقاء التخلص المبرمج، وذلك على العوائق، ينبع من إلقاء التخلص المبرمج.
  4. ينبع من إلقاء التخلص المبرمج، وفقاً لبيان مجلس الشيوخ الكهربائي، ثم إلقاء التخلص المبرمج.


## نوع التخلص والصيانة

العمل	الأصل
1- إلقاء التخلص المبرمج	1. ينبع من إلقاء التخلص المبرمج، ثم إلقاء التخلص المبرمج.
2- إلقاء التخلص المبرمج	2. ثم إلقاء التخلص المبرمج.
3- إلقاء التخلص المبرمج	3. ثم إلقاء التخلص المبرمج.
4- إلقاء التخلص المبرمج	4. ثم إلقاء التخلص المبرمج.
5- إلقاء التخلص المبرمج	5. ثم إلقاء التخلص المبرمج.

- ينبع من إلقاء التخلص المبرمج على العوائق.
1. عزل عن طبيعي أو بلا عزل له غير مصالحة بالوجه الآخر.
  2. عزل عن طبيعي ينبع من مدخل الشفاء أو الأجهزة الكهربائية.

# For you. For life.

مخطط الأسلاك لجنة الهواء



فصل قابس الجهاز أثناء العمل والتنظيف

تحذر: لا ينبع من إلقاء التخلص المبرمج من مصدر التيار الكهربائي قبل إزالة الغطاء من مرجع الهواء.

تحذر: لا ينبع من إلقاء التخلص المبرمج من مصدر التيار الكهربائي قبل إزالة الغطاء من مرجع الهواء.

11

**GEEPAS®**

## CUSTOMER HAPPINESS CENTER

**UNITED ARAB EMIRATES - DUBAI**

Customer Happiness Center, Western International Group,  
P.O.Box # 18742, National Industrial Park, Mina Jebel Ali, Dubai, UAE.  
Tel : +971 4 816 3120, Email: csreception@westernint.com  
**TOLL FREE 800 433 727**

**SAUDI ARABIA - RIYADH**

Customer Happiness Center, Geepas Warehouse,P B Box # 40414  
Ad Dar Al Baida, Riyadh 14516, Saudi Arabia Tel: +966 53 742 1593,  
+ 966 11 286 5540, Email: csiyadh@westernint.com

**SAUDI ARABIA - JEDDAH**

Customer Happiness Center, Al Khumra, Tel: +966 12 653 2525,  
Mob: +966 53 920 3787, Email: csjeddah@westernint.com

**SAUDI ARABIA - JEDDAH**

Customer Happiness Center, Sharafyya, Opp. Post Office  
Tel: +966 12 653 2525, Mob: +966 53 756 6782  
Email: cssharaifyya@westernint.com

**SAUDI ARABIA - IQHAMEES MUSHAIT**

Customer Happiness Center, Khamees Mushait Road, Near Saudi  
Germen Hospital Aseer, Tel: +966 17 220 6616,  
Mob: +966 53 920 3787, Email: cskamis@westernint.com

**SAUDI ARABIA - DAMMAM**

Customer Happiness Center, Al Eatisam Al Khaliji Commercial Ltd. Co.,  
Salman Al Farist St., Al Khalidiyah al Janubiyah  
Tel: +966 3 858 8126 , +966 53 920 3274  
Email: csdammam@westernint.com

**BAHARAIN - MANAMA**

Customer Happiness Center, 2nd Floor, Nesto Supermarket - Building  
No : 513, Shaikh Abdulla Road 329, Manama Center 302, Bahrain.  
Tel : +973 1 722 6177, Mob: +973 6676 5281,  
Email: csbahrain@westernint.com

**KUWAIT**

Customer Happiness Center, Muhammed Al Bahar Building,  
mubarakiya, Kuwait City, Tel : +965 2 487 8055, +965 5 020 6882.  
Email: cskuwait@westernint.com

**OMAN**

Customer Happiness Center, Al Gharbia International LLC, PB No.  
453, PC No.131 Ghala Industrial Area, Sultanate Of Oman  
Tel: +968 2 450 6033, Mob: +968 9 882 4462,  
Email: csoman@westernint.com

**OMAN - BURAIMI**

Customer Happiness Center, East West International LLC , CR No.  
1103699 , Buraimi, Sultanate Of Oman, Tel: +968 2 450 6033,  
Mob: +968 9 446 4661 , +968 9 882 4462,  
Email: csoman@westernint.com, csreception@westernint.com

**OMAN - SALALAH**

Customer Happiness Center, Al Gharbiya International LLC, PB  
No.453,PCNo.131,Al Ikhlas Street, Salalah,Sultanate Of Oman  
Tel: +968 2 329 4069, +968 2 450 6033, Mob : +968 9 882 4462  
Email: csaifalah@westernint.com, csoman@westernint.com

**QATAR**

Customer Happiness Center, Western International Marketing  
Co.W.I.I, P.O Box No: 32480, GWC Bu Sulba Warehousing Park,  
B17 ,Store No.18 Birkat Al Awamer, Al Wakrah Road Wukair  
Tel : +974 4 416 8493, Mob: +974 6 640 1016,  
Email: csqatar@westernint.com

**BANGLADESH - DHAKA**

Customer Happiness Center, Ridge dale Shopping Complex,  
Cha-75/2 North Badda,Progati Sharani,Badda, Dhaka-1212, Shop  
No. 104-105, (1st Floor ), Tel : +88 025 881 1579,  
Mob: +880 174 222 5190, Email: bangladeshhcs3@gmail.com

**NEPAL - KATHMANDU**

Customer Happiness Center, Alliance PVT. LTD, Putalisadak,  
Kathmandu, Nepal, Tel: +9771 416 8211, Mob: +977 98 4103 0824  
Email: allianceaptop123@gmail.com, adm\_ap41@yahoo.com

#### **AFGHANISTAN-KABUL**

M/s Sadaqat Kochi Ltd, Jada Nadir Pashtoon Kherkhwa  
Market Shop No 1  
Tel: +93 202 108001, +93 799 468807

#### **AFGHANISTAN-KABUL**

M/s Sadaqat Kochi Ltd, Jada Nadir Pashtoon Kabul  
Electronics Market Shop No 1.  
Tel: +93 202 109121, +93 782 300200

#### **PAKISTAN-PESHAWAR**

M/s Saleem Khan Electronics Shop No 22-25, Block A  
Khyber Market, Jamrud Road Karkhanoo, Peshawar  
Tel: +92 91 5812436, +92 91 5816619  
Email: S.kltd@yahoo.com

#### **PAKISTAN-LAHORE**

M/s Saleem Electronics, Al Rasheed Trade Center,  
Shop: 2,3,4, Plastic Dara Market,  
Shah-alam Market, Lahore,  
Mob: +92 423 7673957, +92 322 88888864.

#### **INDIA - CALICUT (VADAKARA)**

Customer Happiness Center, Nesto Grand Squire Mall, 2ND Floor,  
Edodi, Vatakara, Calicut, Kerala 673101, India,  
Toll Free : 1800 425 3727, Tel : +91 496 2523940, +91 496 252 3941  
Mob : +91 938 870 6111 , Email: cco@westernint.com

#### **INDIA - KANNUR**

Customer Happiness Center, Kunnath Electro Craft, A Block, 3rd Floor  
Room No.1 Casamarina Complex Talap Kannur - 670004,  
Tel : +91 496 252 3940, Mob : +91 892 177 3390, +91 938 870 6111  
Email: kannurcs110@gmail.com

#### **UK**

##### **Contact details**

Western International group(uk) Ltd  
Unit 5, Alpha Business Park, Bevan Way,  
Smethwick, Birmingham, B66 1BZ.  
UNITED KINGDOM

##### **Customer Service / Technical Support**

Telephone: 01217286969  
Email: support@gEEPAS.co.uk  
Web: www.gEEPAS.co.uk  
\*Register online for warranty.

Following you.  
Following your needs.  
For over 3 decades.

- Available in over 86 Countries
- Over 300 Million Satisfied Customers
- Over 1500 Products
- World Class Service Support



Every GEEPAS product is inspired for you. We strive to have something that can fulfill your life and make it easier. Whether they are Home Appliances, Kitchen Appliances, Entertainment Products, Personal Care or Lighting Devices. We are constantly evolving and innovating to ensure ours that you get to choose from the best, have an range of smart, intelligent solutions. So the next time you look for any GEEPAS products, you know it's made just for you. For life.

**UAE TOLL FREE - 800 433 727**

**INDIA TOLL FREE - 1800 425 3727**

Email : [customercare@gEEPAS.com](mailto:customercare@gEEPAS.com)



LEARN MORE  
ABOUT OUR  
PRODUCTS RANGE

[gEEPAS\\_official](#) [gEEPAS official](#)

MADE IN CHINA

[www.gEEPAS.com](http://www.gEEPAS.com)

#### **Disposal of the appliance**



Correct Disposal of This Product  
(Waste Electrical & Electronic Equipment)  
(Applicable in the European Union and other European countries with separate collection systems)  
This marking on the product, accessories or literature indicates that the product and its electronic accessories  
should not be disposed of with other household waste at the end of their working life. To prevent possible  
harm to the environment or human health from uncontrolled waste disposal, please separate these items  
from other types of waste and recycle them responsibly to promote the sustainable reuse of material  
resources.  
Household users should contact either the retailer where they purchased this product, or their local  
governments office, for details of where and how they can take these items for environmentally safe recycling.  
Business user should contact their supplier and check the terms and conditions of the purchase contract. This  
product and its electronic accessories should not be mixed with other commercial wastes for disposal.